



New Gate

RD-SBM

Instrucciones RD-SBM-v20191218

FIGURA 1



FIGURA 2



FIGURA 3







FIGURA 4



CONEXIONES

ROLL + RD SBM





New Gate

Pol. Ind. Sud-Oest C/Bernat de Rocabertí, 16 Sabadell (Barcelona) 08205
Tel.: 93 721 97 55 e-mail: info@newgate.es

www.newgate.es